




# Assembly instruction Instrukcja montažu Navodila za montažo Upute za montažu Монтажная инструкция Montavimo instrukcija

0757.0674.02


Undervoltage Release – URMPE, Shunt Release – SRMPE  
Wyzwalacz podnapięciowy URMPE, Wyzwalacz napięciowy wzrostowy – SRMPE  
Podnapetnosni sprožnik - URMPE, Daljinski sprožnik – SRMPE  
Podnapetnosni okidač URMPE, Daljinski okidač – SRMPE  
Расцепитель минимального напряжения - URMPE, Независимый расцепитель - SRMPE  
Minimalios itamos atkabiklis




Mounting  
Montaž  
Montaža  
Montaža  
Монтаж  
Montavimas



Disassembly  
Demontaž  
Demontaža  
Демонтаж  
Demontazas



Dimensions  
Wymiary  
Dimenzije  
Dimenzije  
Размеры  
Matmenys



POLSKA  
ETI Polam Sp. z o.o.  
ul. Jana Pawła II 18  
Tel. 0-48/ 23 691 93 00  
Fax. 0-48/ 23 691 93 60  
www.etipolam.com.pl

SLOVENIA  
ETI Elektroelement d.o.o.  
1411 Izlake  
Obrežnja 5  
Phone: +386(0)356 57 570  
Fax. +386(0)356 74 077  
www.etigroup.eu